

IMPEDANCE MATCH DOCUMENTATION




```
numfreq = 500;
y = logspace(1,8,numfreq);
stopFreq = y(numfreq);
startFreq = y(1);
a = double(startFreq);
c = 1;
figure(4);
plot(y);
xlim([0 numfreq]);
ylim([0 20000000]);
yline(15*10^6,'-.b');
while a <= 15000000
a = a*2;
[val, idx] = min(abs(y-a));
minVal=y(idx);
fprintf('%.7f\n',minVal)
yline(minVal);
c = c+1;
disp(c);
end
```



```
Vs = 12;
Zs = 50;
Z1 = 0;
PL = 0;
figure(2);
scatter(Zl,PL,'filled');
x = [];
for c = 1:1000
Z1 = Z1+1;
PL = (((Vs)/(Zs+Z1))^2)*Z1;
disp(PL);
scatter(Zl,PL,'filled');
hold on
x = [x, PL];
end
xline(50);
xline(7);
xline(350);
[M,I] = max(x)
```

Calculations



COIL RADIUS AND DIAMETER (CM)



COIL CROSS SECTION (CM)

Final Coil Inductance: 50.469 uH

Transformer 1

Inductor Impedance Formula: $Xl = 2\Pi fL$

f = frequency

L = Coil Inductance

Coil Impedance at 160.84 Hz: $2\Pi(160.84)(50.469*10^-6) = .05097748\Omega$

Impedance Matching Formula: (Primary Turns/Secondary Turns) =
sqrt(Primary Impedance/Secondary Impednace)

(100/Secondary Turns) = sqrt(7Ω / .05097748 Ω) Secondary Turns: 9 Final Turn Ratio 100:9

```
(100/90) = sqrt(50\Omega / Secondary Impedance)
Secondary Impedance: 2.853
Coil Frequency at Specific Impedance: 0.405 = 2\Pi f(50.469*10^{-6})
Coil Frequency at Specific Impedance: 1277.17Hz
(100/90) = sqrt(350\Omega / Secondary Impedance)
Secondary Impedance: 2.835
Coil Frequency at Specific Impedance: \Omega 2.835 = 2\Pi f(50.469*10^{-6})
Coil Frequency at Specific Impedance: 8.94 Khz
Normalized based on octave allocations: 5.098 Khz
Secondary Impedance at 5.098 \text{ Khz}: 1.61578\Omega
Primary Impedance at 5.098Khz: Ω199.469
Power Transfer at Primary Impedance: 64%
Transformer 2
Boundaries:
                                   ~%43.75 ---- %100 ---- ~%43.75
Primary Impedance:
                                       7\Omega
                                                    50\Omega
                                                                3500
Transformer 1 Frequency Range: 5.098Khz 36.32Khz 328.7Khz
Inductor Impedance Formula: Xl = 2\Pi fL
f = frequency
L = Coil Inductance
Coil Impedance at 5.098Khz Hz: 2\Pi(5098)(50.469*10^{-6}) = 1.61578\Omega
Impedance Matching Formula: (Primary Turns/Secondary Turns) =
sqrt(Primary Impedance/Secondary Impednace)
(100/Secondary Turns) = sqrt(7\Omega / 1.61578\Omega)
Secondary Turns: 48
Final Turn Ratio 100:48
(100/90) = sqrt(50\Omega / Secondary Impedance)
Secondary Impedance: 11.52\Omega
Coil Frequency at Specific Impedance: 11.52\Omega = 2\Pi f(50.469*10^-6)
Coil Frequency at Specific Impedance: 36.3215 Khz
(100/90) = sqrt(350\Omega / Secondary Impedance)
Secondary Impedance: 80.64\Omega
Coil Frequency at Specific Impedance: 80.64\Omega = 2\Pi f(50.469*10^{-6})
Coil Frequency at Specific Impedance: 254.299824 Khz
Normalized based on octave allocations: 328.7Khz
Secondary Impedance at 328.7 Khz: 104.17\Omega
Primary Impedance at 5.098Khz: 452.126\Omega
Power Transfer at Primary Impedance: 35.27%
```

Transformer 3

Inductor Impedance Formula: $Xl = 2\Pi fL$

f = frequency

L = Coil Inductance

Coil Impedance at 328.7 Khz: $2\Pi(328.7 \text{Khz})(50.469*10^-6) = 104.17\Omega$ Impedance Matching Formula: (Primary Turns/Secondary Turns) = sqrt(Primary Impedance/Secondary Impedance)

(100/Secondary Turns) = sqrt(7Ω / 104.17Ω)

Secondary Turns: 48
Final Turn Ratio 10:39

 $(100/90) = sqrt(50\Omega / Secondary Impedance)$

Secondary Impedance: 760.5Ω

Coil Frequency at Specific Impedance: $760.5\Omega = 2\Pi f(50.469*10^{-6})$

Coil Frequency at Specific Impedance: 2.398 Mhz

Coil Impedance for a Frequency of 21.215Mhz: $6723.9\Omega = 2\Pi(2398251)$

 $(50.469*10^{-6})$

Primary Impedance: 442.07

Power Delivery at this Impedance: %36.51

Lower Bound	Upper Bound	Span		Turn Ratio	~43.75% Max Power100% Max Power		~43.75% Max Power
160.84Hz	316.95Hz	156.110Hz					
316.95Hz	645.08Hz	328.130Hz					
645.08Hz	1.271KHz	615.920Hz	Transformer 1	100:9	160.84 Hz	1277.17 Hz	5.098 Khz (64%)
1.271KHz	2.587KHz	1.3160KHz					
2.587KHz	5.098KHz	2.511KHz					
5.098KHz	10.376KHz	5.278KHz					
10.376KHz	20.446KHz	10.070KHz					
20.446KHz	41.613KHz	21.1670KHz					
41.613KHz	82.002KHz	40.389KHz	Transformer 2	100:48	5.098 Khz	36.3285 Khz	328.877 Khz (35.27%)
82.002KHz	161.590KHz	79.588KHz					
161.590KHz	328.877KHz	167.287KHz					
328.877KHz	648.071KHz	319.194KHz					
648.071KHz	1.328MHz	680.0KHz					
1.328MHz	2.599MHz	1.271MHz					
2.599MHz	5.289MHz	2.690MHz	Transformer 3	10:39	328.877 Khz	2.39721 Mhz	21.215MHz (36.51%)
5.289MHz	10.424MHz	5.135MHz					
10.424MHz	21.215MHz	10.791MHz					